

Operating Instructions

Congratulations on your purchase of this premium quality BOSTITCH Electric Pencil Sharpener. With proper use and care, this sharpener will serve you well for many years.

important:

Please read these instructions completely and carefully before operating your new electric sharpener. Keep this instruction sheet for future reference.

Features:

EPS10HC Quiet Sharp 6™ Classroom Pencil Sharpener

- · Sharpens multiple pencil sizes
- . Unique angled cutters for controlled sharpening
- Tip Saver Technology to prevent over sharpening
- . High capacity easy clean shavings receptacle
- · Safety shut-off feature prohibits operation when blades are exposed
- . Quiet heavy duty long life motor with thermal protection for added safety
- Extra long 6 foot power cord

EPS12HC Pro Sharp 6™ Commercial Pencil Sharpener

- · Sharpens multiple pencil sizes
- · Unique angled cutters for controlled sharpening
- · Dual helical cutter
- Tip Saver Technology to prevent over sharpening
- High capacity easy clean shavings receptacle
- · Safety shut-off feature prohibits operation when blades are exposed
- Industrial fan cooled motor with thermal protection for long life
- · Extra long 6 foot power cord

Caution:

- 1. Only plug sharpener into a standard 126 V AC outlet located near and easily accessible to the unit.
- 2. This unit must be unplugged to disable power in case of a malfunction.
- 3. To extend the life of the motor, remove the pencil from the sharpener opening once point is sharpened.
- Refrain from inserting hard materials such as pans, mechanical pencils, chalk, crayons or soft coloring pencils which will damage or clog the cutter blades.
- 5. In the event the motor should overheat, a safety device (thermal switch) will activate to protect the motor from damage. If the thermal switch is activated, allow the sharpener to cool for approximately 20 to 30 minutes to reset automatically.
- 6. An integral safety device prevents operation unless the shaving receptacle is firmly in place.
- 7. Unplug the sharpener before cleaning with damped cloth and mild soap solution.

How to Use:

- 1. Insert the AC plug into any standard 120 V AC outlet.
- 2. Rotate the pencil size selector dial to the correct pencil size. The size for a standard no. 2 pencil is marked with an "S" on the EPS10HC and a ↑ on the EPS12HC.
- 3. Insert the pencil into the pencil sharpener opening to sharpen
- 4. At the end of the sharpening cycle, the Tip Saver Technology™ feature will indicate the pencil is sharpened by a change in motor sound and a decrease in resistance. No additional force should be applied to the pencil.
- Pull out pencil at the end of the sharpening cycle.
- 6. For trouble-free operation, empty the shavings receptable frequently.

Note: Pencils with un-centered lead will not sharpen evenly.

Specifications:

Model	Power Source	Current	Dimensions (W x L x H)	Weight
EPS10HC	'AC120 V, 60Hz	1.9A	4-1/3 x 8-1/2 x 6-13/16	3.3 lbs (1.5 kg)
EPS12HC		2.1A	(110 x 215 x 173mm)	4.2 lbs (1.9 kg)

Three Year Limited Warranty

Stanley Fastening Systems, L.P. warrants this product to the original purchase against any defect in material or workmanship, and agrees to repair or replace, at Stanley Fastening Systems, L.P.'s option, any defect of that material or workmanship. This warranty is not transferable, It only covers damage resulting from defects in material and workmanship, and it does not over conditions or malfunctions resulting from normal wear, neglect, abuse, accident or repairs made by other than our regional repair center or authorized warranty service centers. Driver blades, bumpers, and o-rings are considered normally wearing parts.

THIS WARRANTY IS IN LIEU OF ALL OTHER EXPRESS OR IMPLIED WARRANTIES. REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER. STANLEY FASTENING SYSTEMS. I.E. SHALL, NOT BE HELD LIABLE FOR ANY INCIDENTAL OR CONSCOUNTIAL DAMAGES FOR BREACH OF ANY WARRANTY OR THESE PRODUCTS.

This warranty is limited to sales in the United States and Conada. Some states do not allow limitations on how long an implied warranty lasts, or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

To obtain warranty service, return the product at your expense together with proof of purchase to a Stanley-Bostitch Regional or Authorized Warranty Repair Center. You may call us at 1-800-556-6596 for the location of authorized warranty service centers in your area.

167153REVA 02/05